PRODUCT INTRODUCTION>>

Product parameter:

Product model	YB-3500W
Battery Capacity	25.6V/120Ah
Battery Energy	3072Wh
Battery Type	LifePo4 battery
Inverter Power	3500W
Output Voltage	220V
Rated Frequency	50Hz
DC Output	24V/5A
USB Output	5V/3A
Discharge	Use of 50W appliances
Time	≈ 102H
(Max) PV Panel input	720–1000W
AC Charge input	29.2V
Charging current	20A
Product size	58×28×35cm
Packaging and weight	
Gift box size	/
Gross weight 1 pcs.	/
Outer box size/4 pcs.	66×34×48cm
Gross weight of 4 pcs.	38KG
Warranty	2 years
Packing List	
LED light (5 metre cable)	5W × 2 sets
AC Charger	1 pc
User's Manual	1 pc

PRODUCT INTRODUCTION

CAUTION:

1. Please keep dry and stay away from fire.
2. Do not disassemble, puncture or squeeze the portable power station.
3. Please recycle and dispose of the product in accordance with local laws and regulations.
4. Please hand it over to a professional recycling company for disposal.

YACHU portable power station

INSTRUCTIONS



Thank you for purchasing our products.
Please read this manual carefully before use and keep it properly for reference.

After-sales service:

Dear users, thank you for buying and using the company's products. According to the national warranty provisions, self-use account from the date of signature, with effective bills, you will enjoy the whole free warranty service for two year. Service commitment is as follows:

1. If the product fails in the normal use process, consumers can obtain free maintenance services by warranty card or invoice, except for human failure.

2. Under any of the following circumstances, it is not covered by the warranty but can be repaired for a fee:

A. Faults caused by users' failure to operate according to the instructions;
B. Damage caused by improper storage, maintenance and use of the user;
C. Faults occurred after users disassemble, modify or install other functions;
D. Use of household products for non-household use (such as production, business, etc.);
E. Damage caused by force (such as lightning, fire, earthquake, flood and other natural disasters);
F. There is no purchase bill or voucher, and the bill is illegible or altered.

3. When the user needs warranty service, please provide the completed guarantee card and purchase voucher.

Guarantee card

Product information (required):

Sales merchant: _____

Product model: _____

Date of purchase: _____

Contact information: _____

User address: _____

Return reason/fault description:

_____

Safety Instructions and Maintenance:

1. Please read the manual carefully before using the product.

2. To reduce the risk of injury, please pay more attention when using this product near children.

3. Do not put fingers, palms or any part of your body into the product.

4. Use of unrecommended accessories may cause fire, electric shock or personal injury.

5. Do not use damaged or modified battery packs or devices.

6. Do not operate the portable power station with a damaged cord, plug or output cable. Otherwise it may cause a short circuit and risk of fire.

7. Please hand the power station to a qualified service provider for repair or maintenance. Do not disassemble the portable power station by yourself, as a wrong disassembly method may cause the risk of fire or electric shock.

9. Please charge the product in a well-ventilated place; do not obstruct the air circulation.

11. Please do not expose the product to fire or excessive heat.

12. Only repairs by qualified service personnel.

13. Please do not exceed the specified input AC voltage. Otherwise it may cause product failure.

Please keep the safety instructions properly.